

## COMPONENT AND SYSTEM INDEX

Name	Group-page	Name	Group-page
AUDIO SYSTEMS . . . . .	8F-1	STANDARD SERVICE PROCEDURES . . . . .	9-1
GENERAL INFORMATION . . . . .	8F-1	EXHAUST SYSTEM AND INTAKE MANIFOLD . . . . .	11-1
POWER ANTENNA RELAY . . . . .	8F-12	EXHAUST SYSTEM . . . . .	11-1
POWER RADIO ANTENNA . . . . .	8F-11	EXHAUST SYSTEM DIAGNOSIS . . . . .	11-3
SERVICE PROCEDURES . . . . .	8F-8	SERVICE PROCEDURES . . . . .	11-4
STANDARD RADIO ANTENNA . . . . .	8F-10	TORQUE SPECIFICATIONS . . . . .	11-10
TEST PROCEDURES . . . . .	8F-2	FRAME AND BUMPERS . . . . .	13-1
BATTERY/STARTER MOTOR/GENERATOR SERVICE . . . . .	8B-1	BUMPERS . . . . .	13-4
BATTERY SERVICE PROCEDURES . . . . .	8B-1	FRAME . . . . .	13-1
ENGINE STARTER MOTOR SERVICE PROCEDURES . . . . .	8B-4	FRONT SUSPENSION AND AXLE . . . . .	2-1
GENERATOR SERVICE PROCEDURES . . . . .	8B-6	AXLE NOISE/VIBRATION DIAGNOSIS . . . . .	2-13
SPECIFICATIONS . . . . .	8B-9	FRONT SUSPENSION . . . . .	2-9
BODY COMPONENTS . . . . .	23-1	FRONT WHEEL ALIGNMENT . . . . .	2-4
DOORS . . . . .	23-15	GENERAL INFORMATION . . . . .	2-1
EXTERIOR COMPONENTS . . . . .	23-1	MODEL 30 AXLE AND TUBE AXLE (2WD) . . . . .	2-17
FIXED WINDOW GLASS . . . . .	23-25	TORQUE SPECIFICATIONS . . . . .	2-41
INTERIOR COMPONENTS . . . . .	23-29	FUEL SYSTEM . . . . .	14-1
PAINT CODE CHART . . . . .	23-43	ACCELERATOR PEDAL AND THROTTLE CABLE . . . . .	14-15
POWER SUNROOF . . . . .	23-12	FUEL DELIVERY SYSTEM . . . . .	14-3
REFINISHING PROCEDURES . . . . .	23-43	FUEL TANKS . . . . .	14-12
UNDERBODY COMPONENTS . . . . .	23-28	GENERAL INFORMATION . . . . .	14-1
BRAKES . . . . .	5-1	MPI SYSTEM—4.0L ENGINE—COMPONENT	
ANTILOCK BRAKE OPERATION . . . . .	5-14	DESCRIPTION/SYSTEM OPERATION . . . . .	14-17
ANTILOCK BRAKE SYSTEM DIAGNOSIS . . . . .	5-3	MPI SYSTEM—4.0L ENGINE—COMPONENT	
ANTILOCK ELECTRONIC COMPONENT SERVICE . . . . .	5-28	REMOVAL/INSTALLATION . . . . .	14-46
BRAKE ADJUSTMENTS-FLUID LEVEL-BRAKE		MPI SYSTEM—4.0L ENGINE—GENERAL	
BLEEDING . . . . .	5-10	DIAGNOSIS . . . . .	14-29
BRAKE PEDAL AND SWITCH SERVICE . . . . .	5-48	MPI SYSTEM—5.2L ENGINE—COMPONENT	
DISC BRAKE SERVICE . . . . .	5-33	DESCRIPTION/SYSTEM OPERATION . . . . .	14-53
DRUM BRAKE SERVICE . . . . .	5-41	MPI SYSTEM—5.2L ENGINE—COMPONENT	
GENERAL INFORMATION . . . . .	5-1	REMOVAL/INSTALLATION . . . . .	14-85
MASTER CYLINDER—HCU—COMBINATION		MPI SYSTEM—5.2L ENGINE—GENERAL	
VALVE—BRAKELINES . . . . .	5-21	DIAGNOSIS . . . . .	14-66
PARKING BRAKE SERVICE . . . . .	5-44	SPECIFICATIONS . . . . .	14-95
POWER BRAKE BOOSTER SERVICE . . . . .	5-26	BATTERY/STARTING/CHARGING SYSTEMS	
SERVICE BRAKE COMPONENT DIAGNOSIS . . . . .	5-5	DIAGNOSTICS . . . . .	8-1
SPECIFICATIONS . . . . .	5-50	BATTERY TEST PROCEDURES . . . . .	8-2
CHIME/BUZZER WARNING SYSTEMS . . . . .	8U-1	ENGINE STARTER MOTOR TEST PROCEDURES . . . . .	8-10
SEAT BELT WARNING SYSTEM . . . . .	8U-1	GENERATOR TEST PROCEDURES ON VEHICLE . . . . .	8-15
CLUTCH . . . . .	6-1	IGNITION OFF DRAW (IOD) . . . . .	8-9
CLUTCH DIAGNOSIS . . . . .	6-2	SPECIFICATIONS . . . . .	8-21
CLUTCH SERVICE . . . . .	6-9	HEATING AND AIR CONDITIONING . . . . .	24-1
COOLING SYSTEM . . . . .	7-1	CLIMATE CONTROL SYSTEM . . . . .	24-39
ENGINE ACCESSORY DRIVE BELTS . . . . .	7-32	COMPRESSOR SERVICE PROCEDURES . . . . .	24-36
ENGINE BLOCK HEATER . . . . .	7-38	GENERAL INFORMATION . . . . .	24-1
DIAGNOSIS . . . . .	7-2	HEATER AND AIR CONDITIONING SYSTEM	
SERVICE PROCEDURES . . . . .	7-6	DIAGNOSTICS . . . . .	24-8
SPECIFICATIONS . . . . .	7-40	REFRIGERANT SERVICE PROCEDURES . . . . .	24-29
ELECTRICAL . . . . .	8A-1	TORQUE SPECIFICATIONS . . . . .	24-51
GROUP INDEX . . . . .	8A-1	HORNS . . . . .	8G-1
EMISSION CONTROL SYSTEMS . . . . .	25-1	GENERAL INFORMATION . . . . .	8G-1
COMPONENT REMOVAL/INSTALLATION . . . . .	25-13	HORN REPLACEMENT . . . . .	8G-3
EVAPORATIVE EMISSION CONTROLS . . . . .	25-4	HORNS SOUND CONTINUOUSLY . . . . .	8G-2
EXHAUST EMISSION CONTROLS . . . . .	25-9	HORNS WILL NOT SOUND . . . . .	8G-1
GENERAL INFORMATION . . . . .	25-1	HORN SWITCH REPLACEMENT . . . . .	8G-2
ENGINES . . . . .	9-1	RELAY REPLACEMENT . . . . .	8G-3
4.0L ENGINE SERVICE PROCEDURES . . . . .	9-9	IGNITION SYSTEMS . . . . .	8D-1
5.2L ENGINE SERVICE PROCEDURES . . . . .	9-47	COMPONENT IDENTIFICATION/SYSTEM OPERATION . . . . .	8D-1
ENGINE DIAGNOSIS . . . . .	9-5	COMPONENT REMOVAL/INSTALLATION . . . . .	8D-21

DIAGNOSTICS/SERVICE PROCEDURES . . . . .	8D-8	AIR BAG SYSTEM GENERAL INFORMATION . . . . .	8M-1
IGNITION SWITCH . . . . .	8D-35	AIR BAG SYSTEM SERVICE PROCEDURES . . . . .	8M-4
SPECIFICATIONS . . . . .	8D-38	STEERING . . . . .	19-1
INSTRUMENT PANEL AND GAUGES . . . . .	8E-1	AUTOMATIC TRANSMISSION SHIFTER/IGNITION	
GRAPHIC DISPLAY MODULE . . . . .	8E-19	INTERLOCK MECHANISM . . . . .	19-38
INSTRUMENT CLUSTER DIAGNOSIS . . . . .	8E-3	GENERAL INFORMATION . . . . .	19-1
INSTRUMENT CLUSTER GENERAL INFORMATION . . . . .	8E-1	POWER STEERING PUMP . . . . .	19-9
INSTRUMENT CLUSTER SERVICE PROCEDURES . . . . .	8E-5	POWER STEERING SYSTEM DIAGNOSIS . . . . .	19-3
INSTRUMENT PANEL SERVICE PROCEDURES . . . . .	8E-22	RECIRCULATING BALL POWER STEERING GEAR . . . . .	19-17
VEHICLE INFORMATION CENTER (VIC) . . . . .	8E-11	STEERING COLUMN . . . . .	19-33
INTRODUCTION . . . . .	Intro-1	STEERING LINKAGE . . . . .	19-14
DESIGNATIONS, LABELS/PLATES/DECALS, CODES		TORQUE SPECIFICATIONS . . . . .	19-40
AND DIMENSIONS/WEIGHTS . . . . .	Intro-1	TRANSMISSION AND TRANSFER CASE . . . . .	21-151
MEASUREMENT AND TORQUE SPECIFICATIONS . . . . .	Intro-5	46RH AUTOMATIC TRANSMISSION . . . . .	21-151
LAMPS . . . . .	8L-1	46RH TRANSMISSION DIAGNOSIS . . . . .	21-157
BULB APPLICATION . . . . .	8L-17	46RH TRANSMISSION/OVERDRIVE REMOVAL	
DIAGNOSTIC PROCEDURES . . . . .	8L-1	AND INSTALLATION . . . . .	21-200
EXTERIOR LAMP SYSTEMS . . . . .	8L-12	AW-4 AUTOMATIC TRANSMISSION . . . . .	21-34
GENERAL INFORMATION . . . . .	8L-1	AW-4 IN-VEHICLE SERVICE . . . . .	21-51
INTERIOR LAMPS . . . . .	8L-9	AW-4 TRANSMISSION DIAGNOSIS . . . . .	21-45
SERVICE PROCEDURES . . . . .	8L-3	AW-4 TRANSMISSION OVERHAUL . . . . .	21-72
LUBRICATION AND MAINTENANCE . . . . .	0-1	AW-4 TRANSMISSION/CONVERTER REMOVAL	
CHASSIS AND BODY . . . . .	0-21	AND INSTALLATION . . . . .	21-69
DRIVETRAIN . . . . .	0-17	AX 15 MANUAL TRANSMISSION . . . . .	21-1
ENGINE MAINTENANCE . . . . .	0-11	GENERAL INFORMATION . . . . .	21-34
GENERAL INFORMATION . . . . .	0-1	GENERAL INFORMATION . . . . .	21-151
OVERHEAD CONSOLE . . . . .	8C-1	IN-VEHICLE SERVICE—46RH . . . . .	21-190
POWER DOOR LOCKS . . . . .	8P-1	NP231 TRANSFER CASE . . . . .	21-271
KEYLESS ENTRY . . . . .	8P-5	NP242 TRANSFER CASE . . . . .	21-292
POWER LOCKS . . . . .	8P-1	NP249 TRANSFER CASE . . . . .	21-319
POWER MIRRORS . . . . .	8T-1	OVERDRIVE UNIT OVERHAUL—46RH . . . . .	21-253
AUTOMATIC DAY/NIGHT REAR VIEW MIRROR . . . . .	8T-6	SPECIFICATIONS . . . . .	21-345
POWER SIDE MIRRORS . . . . .	8T-1	TRANSMISSION OVERHAUL—46RH . . . . .	21-208
POWER SEATS . . . . .	8R-1	TURN SIGNALS AND HAZARD WARNING FLASHER . . . . .	8J-1
POWER WINDOWS . . . . .	8S-1	GENERAL INFORMATION . . . . .	8J-1
PROPELLER SHAFTS . . . . .	16-1	MULTI-FUNCTION SWITCH SERVICE PROCEDURES . . . . .	8J-4
GENERAL INFORMATION . . . . .	16-1	MULTI-FUNCTION SWITCH TESTING PROCEDURES . . . . .	8J-3
PROPELLER SHAFT REPLACEMENT . . . . .	16-7	VEHICLE SPEED CONTROL SYSTEM . . . . .	8H-1
SERVICE DIAGNOSIS/PROCEDURES . . . . .	16-3	SERVICE PROCEDURES . . . . .	8H-9
TORQUE SPECIFICATIONS . . . . .	16-14	TEST PROCEDURES . . . . .	8H-5
UNIVERSAL JOINT REPLACEMENT . . . . .	16-9	VEHICLE THEFT SECURITY SYSTEM . . . . .	8Q-1
REAR SUSPENSION AND AXLES . . . . .	3-1	WHEELS AND TIRES . . . . .	22-1
AXLE NOISE/VIBRATION DIAGNOSIS . . . . .	3-6	SPECIFICATIONS . . . . .	22-12
GENERAL INFORMATION . . . . .	3-1	TIRES . . . . .	22-1
MODEL 35 AXLE . . . . .	3-10	VEHICLE VIBRATION . . . . .	22-10
REAR SUSPENSION . . . . .	3-3	WHEELS . . . . .	22-6
TORQUE SPECIFICATIONS . . . . .	3-32	WINDSHIELD WIPER AND WASHER SYSTEMS . . . . .	8K-1
TRAC-LOK DIFFERENTIAL . . . . .	3-27	FRONT WIPERS/WASHERS . . . . .	8K-1
REAR WINDOW DEFOGGER . . . . .	8N-1	REAR WINDOW WIPER/WASHER . . . . .	8K-7
DIAGNOSIS . . . . .	8N-2	WIRING DIAGRAMS . . . . .	8W-1
GENERAL . . . . .	8N-1	COMPONENT IDENTIFICATION . . . . .	8W-11
SERVICE PROCEDURES . . . . .	8N-4	GENERAL INFORMATION . . . . .	8W-1
RESTRAINT SYSTEMS . . . . .	8M-1	SPlice LOCATIONS . . . . .	8W-26
AIR BAG SYSTEM . . . . .	8M-1	WIRING DIAGRAMS . . . . .	8W-35