

POWER MIRROR SYSTEMS

CONTENTS

	page		page
AUTOMATIC DAY/NIGHT MIRROR	6	OUTSIDE POWER MIRRORS	1

OUTSIDE POWER MIRRORS

INDEX

	page		page
GENERAL INFORMATION		DIAGNOSIS AND TESTING	
INTRODUCTION	1	POWER MIRROR SYSTEM	2
MEMORY SYSTEM	1	POWER MIRROR	3
DESCRIPTION AND OPERATION		REMOVAL AND INSTALLATION	
DOOR MODULE	2	DOOR MODULE	4
POWER MIRROR SWITCH	2	POWER MIRROR	5
POWER MIRROR	2		

GENERAL INFORMATION

INTRODUCTION

Power operated and heated outside rear view mirrors are standard factory-installed equipment on this model. Following are general descriptions of the major components in the power mirror system.

Refer to 8W-62 - Power Mirrors in Group 8W - Wiring Diagrams for complete circuit descriptions and diagrams. Refer to the owner's manual for more information on the features and use of this system.

NOTE: This group covers both Left-Hand Drive (LHD) and Right-Hand Drive (RHD) versions of this model. Whenever required and feasible, the RHD versions of affected vehicle components have been constructed as mirror-image of the LHD versions. While most of the illustrations used in this group represent only the LHD version, the diagnostic and service procedures outlined can generally be applied to either version. Exceptions to this rule have been clearly identified as LHD or RHD, if a special illustration or procedure is required.

MEMORY SYSTEM

An electronic memory system is an available option on this model. The memory system is able to store and recall the driver side power seat positions

(including power lumbar and recliner positions), and both outside power mirror positions for two drivers. For vehicles with a radio connected to the Chrysler Collision Detection (CCD) data bus network, the memory system is also able to store and recall ten radio station presets (including last station tuned) for two drivers. The memory system will automatically return to all of these settings when the corresponding button (Driver 1 or 2) of the memory switch on the driver side front door trim panel is depressed, or when the doors are unlocked using the corresponding (Driver 1 or 2) Remote Keyless Entry (RKE) transmitter.

The Driver Door Module (DDM) receives hard-wired input from the memory set/select switch on the driver side front door trim panel. The DDM also receives messages on the CCD data bus from the RKE receiver in the Passenger Door Module (PDM) for the memory select function. The DDM processes these inputs and sends messages to the PDM, the Memory Seat Module (MSM), and the radio (if CCD data bus capable) on the CCD data bus for memory recall.

The CCD data bus network allows the sharing of sensor information. This helps to reduce wire harness complexity, reduce internal controller hardware, and reduce component sensor current loads. At the same time, this system provides increased reliability,

GENERAL INFORMATION (Continued)

enhanced diagnostics, and allows the addition of many new feature capabilities.

This group covers only the conventional diagnostic procedures for the power mirror system components. For diagnosis of the memory system, use of a DRB scan tool and the proper Body Diagnostic Procedures manual are recommended. For additional information on the features and functions of the memory system, refer to the vehicle owner's manual.

DESCRIPTION AND OPERATION

POWER MIRROR

The power mirrors are connected to battery feed at all times. Each mirror head contains two electric motors, two drive mechanisms, an electric heating element, horizontal and vertical position sensors for the memory system option, and the mirror glass. One motor and drive controls mirror up-and-down movement, and the other controls right-and-left movement.

An optional driver side outside electrochromic mirror is able to automatically change its reflectance level. This mirror is controlled by the circuitry of the automatic day/night inside rear view mirror. A thin layer of electrochromic material between two pieces of conductive glass make up the face of the mirror. Two photocell sensors on the inside rear view mirror are used to monitor light levels and adjust the reflectance of both the inside and driver side outside mirrors. This change in reflectance helps to reduce the glare of headlamps approaching the vehicle from the rear. Refer to the Automatic Day/Night Mirror section of this group for more information on the operation of this system.

The power mirror assembly cannot be repaired. Only the mirror glass and glass case are serviced separately. If any other component of the power mirror unit is faulty or damaged, the entire assembly must be replaced.

POWER MIRROR SWITCH

Both the right and left power outside mirrors are controlled by a single multi-function switch unit located on the driver side door trim panel. This switch unit is integral to the Driver Door Module (DDM).

A selector switch is moved right (right mirror control), left (left mirror control), or center to turn the power outside mirror control off. Then one of four directional control buttons is depressed to control movement of the selected mirror up, down, right, or left.

The power mirror switch cannot be repaired and, if faulty or damaged, the DDM unit must be replaced.

DOOR MODULE

A Driver Door Module (DDM) and a Passenger Door Module (PDM) are used on this model to control and integrate many of the electronic features and functions on the vehicle. The DDM and PDM communicate with each other, and with other vehicle modules on the Chrysler Collision Detection (CCD) data bus network.

The CCD data bus network allows the sharing of sensor information. This helps to reduce wire harness complexity, internal controller hardware, and component sensor current loads. At the same time, this system provides increased reliability, enhanced diagnostics, and allows the addition of many new feature capabilities.

Each door module controls the positioning of its respective outside mirror. When the power mirror switch on the DDM is used to position the passenger side outside mirror, the DDM sends mirror positioning messages to the PDM on the CCD data bus. The PDM then moves the passenger side mirror accordingly.

Both the PDM and DDM respond to the defogger switch status messages sent by the Body Control Module (BCM) on the CCD data bus to control the heater elements of their respective mirrors. Refer to Group 8N - Electrically Heated Systems for more information on this feature.

On models equipped with the optional memory system, each door module stores the Driver 1 and 2 mirror position information for its respective mirror. When the DDM receives a Driver 1 or 2 signal from the Memory Switch or from the Remote Keyless Entry (RKE) receiver in the PDM, the DDM positions the driver side mirror and sends a memory recall message back to the PDM on the CCD data bus to position the passenger side mirror.

For diagnosis of the DDM, PDM, or the CCD data bus network, refer to the proper Body Diagnostic Procedures manual.

DIAGNOSIS AND TESTING

POWER MIRROR SYSTEM

If only one power mirror is inoperative, or partially inoperative, see the tests under Power Mirror in this group. If both power mirrors are inoperative, proceed as follows. For circuit descriptions and diagrams, refer to 8W-62 - Power Mirrors in Group 8W - Wiring Diagrams.

NOTE: The following tests may not prove conclusive in the diagnosis of this system. The most reliable, efficient, and accurate means to diagnose this system involves the use of a DRB scan tool and the proper Body Diagnostic Procedures Manual.

DIAGNOSIS AND TESTING (Continued)

(1) Check the circuit breaker in the junction block. If OK, go to Step 2. If not OK, replace the faulty circuit breaker.

(2) Check the fuse in the Power Distribution Center (PDC). If OK, go to Step 3. If not OK, replace the faulty fuse.

(3) Disconnect and isolate the battery negative cable. Remove the driver side door trim panel as described in this group. Check the 12-way Driver Door Module (DDM) wire harness connector to see that it is fully seated in the door module receptacle. If OK, go to Step 4. If not OK, install the wire harness connector properly.

(4) Unplug the 12-way wire harness connector from the DDM. Check for continuity between the ground circuit cavity of the DDM wire harness connector and a good ground. There should be continuity. If OK, go to Step 5. If not OK, repair the open circuit as required.

(5) Connect the battery negative cable. Check for battery voltage at the fused B(+) circuit cavity of the DDM wire harness connector. If OK, use a DRB scan tool and the proper Body Diagnostic Procedures manual to test both door modules and the CCD data bus. If not OK, repair the open circuit as required.

POWER MIRROR

If both power mirrors are inoperative, see the tests under Power Mirror System in this group. If only one power mirror is inoperative, or partially inoperative, refer to the symptom diagnosis as follows. For circuit descriptions and diagrams, refer to 8W-62 - Power Mirrors in Group 8W - Wiring Diagrams.

LIMITED OR NO MIRROR MOVEMENT

(1) Disconnect and isolate the battery negative cable. Remove the front door trim panel on the side of the inoperative mirror as described under Door Module in this group.


(2) Unplug the mirror wire harness connector from the door module. Using two jumper wires, test the mirror as shown in the Mirror Test chart (Fig. 1). If the mirror tests OK, use a DRB scan tool and the proper Body Diagnostic Procedures manual to test the door module and the CCD data bus. If the mirror does not test OK, replace the faulty mirror.

NO MIRROR HEAT

If both mirror heaters are inoperative, refer to Group 8N - Electrically Heated Systems to test the Rear Defogger System.

(1) Disconnect and isolate the battery negative cable. Remove the front door trim panel on the side of the inoperative mirror as described under Door Module in this group.

(2) Unplug the mirror wire harness connector from the door module. Check for continuity between the



POWER MIRROR HARNESS CONNECTOR		
APPLY 12 VOLTS TO:	APPLY GROUND TO:	MIRROR REACTION
A	G	LEFT
G	A	RIGHT
H	G	UP
G	H	DOWN

80a1374e

POWER MIRROR HARNESS CONNECTOR		
APPLY 12 VOLTS TO:	APPLY GROUND TO:	MIRROR REACTION
A	G	LEFT
G	A	RIGHT
H	G	UP
G	H	DOWN

Fig. 1 Mirror Test

heater switched ground circuit cavity and the heater 12V supply circuit cavity of the mirror wire harness connector. There should be continuity. If OK, use a DRB scan tool and the proper Body Diagnostic Procedures manual to test the door module and the CCD data bus. If not OK, replace the faulty mirror.

NO MIRROR DIMMING (Driver Side Only)

(1) Test the operation of the Automatic Day/Night Mirror as described in this group. If OK, go to Step 2. If not OK, repair the automatic day/night mirror unit as necessary before you proceed.

(2) Disconnect and isolate the battery negative cable. Remove the driver side front door trim panel as described under Door Module in this group.

(3) Unplug the 2-way electrochromic mirror wire harness connector from the driver side outside mirror and connect a voltmeter to the door wire harness half of the connector. Perform the automatic day/night mirror test as described in this group, while observing the voltmeter. A voltmeter reading of 1.45 ± 0.05 volts indicates a proper dimming signal is being received at the mirror wire harness connector. If OK,

DIAGNOSIS AND TESTING (Continued)

replace the faulty power mirror. If not OK, repair the circuits to the automatic day/night mirror as required.

NO MIRROR MEMORY

For diagnosis of the memory system, the use of a DRB scan tool and the proper Body Diagnostic Procedures manual are recommended.

REMOVAL AND INSTALLATION

DOOR MODULE

(1) Disconnect and isolate the battery negative cable.

(2) Remove the bezel near the inside door latch release handle by inserting a straight-bladed screwdriver in the notched end and prying gently upwards.

(3) Remove the door trim panel mounting screw located in the bezel opening near the inside door latch release handle (Fig. 2).




Fig. 2 Front Door Trim Panel Remove/Install

(4) Remove the trim cap and screw near the rear of the door armrest.

(5) Remove the trim cap and screw at the upper front corner of the trim panel.

(6) Remove the screw located above the front door speaker grille.

(7) Using a wide flat-bladed tool such as a trim stick, pry the trim panel away from the door around the perimeter and remove the trim panel.

NOTE: To aid in the removal of the trim panel, start at the bottom of the panel.

(8) Unplug the wire harness connectors from the door module and the door courtesy lamp, if equipped.

(9) Remove the five screws that secure the door module to the door trim panel (Fig. 3).




Fig. 3 Door Module Remove/Install

(10) Remove the door module from the trim panel.

(11) Reverse the removal procedures to install.

NOTE: If a new door module is installed, the programmable features must be enabled and/or disabled to the customer's preferred settings. Use a DRB scan tool and the proper Body Diagnostic Procedures manual to perform these operations.

REMOVAL AND INSTALLATION (Continued)

POWER MIRROR

(1) Disconnect and isolate the battery negative cable.

(2) Remove the front door trim panel as described under Door Module in this group.

(3) Unplug the electrochromic mirror wire harness connector, if equipped.

(4) Unclip the mirror wire harness(es) from the inner door panel.

(5) Remove the mirror flag seal (Fig. 4).

(6) Remove the three nuts that secure the mirror to the door.

(7) Remove the mirror from the door.

(8) Reverse the removal procedures to install. Tighten the mirror mounting nuts to 7.4 N·m (65 in. lbs.).




Fig. 4 Power Mirror Remove/Install

AUTOMATIC DAY/NIGHT MIRROR

INDEX

	page		page
GENERAL INFORMATION		DIAGNOSIS AND TESTING	
INTRODUCTION	6	AUTOMATIC DAY/NIGHT MIRROR	6
DESCRIPTION AND OPERATION		REMOVAL AND INSTALLATION	
AUTOMATIC DAY/NIGHT MIRROR	6	AUTOMATIC DAY/NIGHT MIRROR	7

GENERAL INFORMATION

INTRODUCTION

An automatic dimming inside day/night rear view mirror and an automatic dimming driver side outside rear view mirror are available factory-installed options on this model. Following is a general description of this optional equipment. Refer to 8W-44 - Interior Lighting and 8W-62 - Power Mirrors in Group 8W - Wiring Diagrams for complete circuit descriptions and diagrams.

NOTE: This group covers both Left-Hand Drive (LHD) and Right-Hand Drive (RHD) versions of this model. Whenever required and feasible, the RHD versions of affected vehicle components have been constructed as mirror-image of the LHD versions. While most of the illustrations used in this group represent only the LHD version, the diagnostic and service procedures outlined can generally be applied to either version. Exceptions to this rule have been clearly identified as LHD or RHD, if a special illustration or procedure is required.

DESCRIPTION AND OPERATION

AUTOMATIC DAY/NIGHT MIRROR

The automatic day/night mirror is able to automatically change its reflectance. A thin layer of electrochromic material between two pieces of conductive glass make up the face of the mirror. Two photocell sensors are used to monitor light levels and adjust the reflectance of the mirror to reduce the glare of headlamps approaching the vehicle from the rear.

The ambient photocell sensor faces forward, to detect the outside light levels. The headlamp sensor faces rearward, to detect the light level received at the rear window side of the mirror. When the difference between the two light levels becomes too great (the light level received at the rear of the mirror is much higher than at the front of the mirror), the mirror begins to darken.

The mirror switch allows the driver a manual control of whether the automatic dimming feature is operational. When On is selected, the mirror switch is lighted by an integral Light-Emitting Diode (LED). The automatic dimming feature will only operate when the ignition switch is in the On position. The mirror also senses the backup lamp circuit, and disables the self-dimming feature whenever the transmission gear selector is in the Reverse position.

On models with an optional electrochromic driver side outside rear view mirror, the signal to control the dimming of that mirror is generated by the automatic day/night inside rear view mirror circuitry. That signal is then delivered to the driver side outside rear view mirror on a hard-wired circuit.

The automatic day/night mirror cannot be repaired. If faulty or damaged, the entire inside rear view mirror assembly must be replaced.

DIAGNOSIS AND TESTING

AUTOMATIC DAY/NIGHT MIRROR

For circuit descriptions and diagrams, refer to 8W-44 - Interior Lighting or 8W-62 Power Mirrors in Group 8W - Wiring Diagrams.


(1) Check the fuse in the junction block. If OK, go to Step 2. If not OK, replace the faulty fuse.

(2) Turn the ignition switch to the On position. Check for battery voltage at the fuse in the junction block. If OK, go to Step 3. If not OK, repair the open circuit to the ignition switch as required.

(3) Unplug the wire harness connector from the mirror (Fig. 1). Check for battery voltage at the fused ignition switch output circuit cavity of the mirror wire harness connector. If OK, go to Step 4. If not OK, repair the open circuit to the junction block as required.

(4) Turn the ignition switch to the Off position. Check for continuity between the ground circuit cavity of the mirror wire harness connector and a good ground. There should be continuity. If OK, go to Step 5. If not OK, repair the circuit to ground as required.

DIAGNOSIS AND TESTING (Continued)



80a1374f

Fig. 1 Automatic Day/Night Mirror

(5) Turn the ignition switch to the On position. Set the parking brake. Place the transmission gear selector lever in the Reverse position. Check for battery voltage at the backup lamp switch output circuit cavity of the mirror wire harness connector. If OK, plug in the mirror wire harness connector and go to Step 6. If not OK, repair the open circuit as required.

(6) Place the transmission gear selector lever in the Neutral position. Place the mirror switch in the On (LED in the switch is lighted) position. Cover the forward facing ambient photocell sensor to keep out any ambient light.

NOTE: The ambient photocell sensor must be covered completely, so that no light reaches the sensor. Use a finger pressed tightly against the sensor, or cover the sensor completely with electrical tape.

(7) Shine a light into the rearward facing headlamp photocell sensor. The mirror should darken. If OK, go to Step 8. If not OK, replace the faulty mirror unit.

(8) With the mirror darkened, place the transmission gear selector lever in the Reverse position. The


mirror should return to its normal reflectance. If not OK, replace the faulty mirror unit.

REMOVAL AND INSTALLATION

AUTOMATIC DAY/NIGHT MIRROR

(1) Disconnect and isolate the battery negative cable.

(2) If so equipped, remove the wire harness cover by grasping the lower portion of the cover and sliding it into the upper portion and off of the mirror base (Fig. 2).

**Fig. 2 Automatic Day/Night Mirror Remove/Install-Typical**

(3) Unplug the wire harness connector from the mirror.

(4) Remove the set screw that secures the mirror to the windshield support button.

(5) Push the mirror up far enough to clear the support button and remove the mirror.

(6) Reverse the removal procedures to install.

